

countdown setting



countdown :

> **press briefly** on the pusher :

by successive pressure set the countdown on the desired minute.

Setting of the countdown from -15 minutes to 0 minutes

At the end of the countdown, your instrument is automatically shifting in chronograph mode and is counting the regatta hours and the minutes until 99 hours, 59 minutes and 59 seconds.

chronograph :

> if you set the countdown on 0 : your instrument is working like a chronograph and is adding the time until 99 hours, 59 minutes and 59 seconds.