



START – STOP – RESET FUNCTION

START FUNCTION :

> press **1x** on the pusher

STOP FUNCTION :

> press **2x** on the pusher

RESET FUNCTION :

(back to countdown)

> press **1x** on the pusher