

catch-up function



catch-up function

> press **2x** on the pusher,

(Why to press 2 x : to avoid any involuntary manipulation of the pusher during the regatta).

What for is the catch function needed : During the departure signal given at -5 minutes you were busy with a sail at the front and you have activated the countdown a few seconds too late.

> By pressing 2 x on the pusher at the -4 minute signal you will be again perfectly on time !